




BHD50

Exploded parts diagram









Part Number	Number	Description	Qty
B4-CASTORBHD	1	Braked Castor	2
B4-CASTORUBHD	2	Castor	2
***	3	Terminal Block	1
***	4	Base Plate	1
***	5	Power Cord	1
***	6	Control Box Bracket	1
***	7	PCB Box Cover	1
***	8	PCB Box	1
***	9	LH Side Lower Panel	1
***	10	Clip Holder	1
***	11	Clip Cover	1
***	12	Rear Cover	1
***	13	Plastic Trim	1
***	14	Cross Beam	1
***	15	RH Side Lower Panel	1
***	16	Plastic Trim	1
***	17	Intermediate Base Plate	1
***	18	Left Plastic Panel	1
***	19	Left Panel	1
***	20	Vent Bracket	1
***	21	Rear Grille	1
***	22	Panel Insulation	1
***	23	Left and Right Air Channel	1
***	24	Top Air Channel	1
***	25	Left Air Vent	1
***	26	Heater	1
***	27	Right Air Vent	1
***	28	Bottom Air Channel	1
***	29	Air Vent Guide 1	1
***	30	Air Vent Guide 2	1
***	31	Cabinet Base Plate	1
***	32	Decorative Cover	2
***	33	Gasket	2
***	34	Decorative Cover Gasket	2
***	35	Cabinet Rear Cover	1
***	36	Rear Insulation	1
***	37	Perforated Panel	1
***	38	Shelf Ladder Rack	2
***	39	Left Side Glass	1
***	40	Right Side Glass	1
***	41	Top Interior Panel	1
B4-LAMPBHD	42	Lamp	1
B4-COVERBHD	43	Lamp Cover	1
***	44	Insulation	1
***	45	Top Cover	1

***	46	Top Front Panel	1
***	47	Curtain Fixing Panel	1
***	48	Insulation	1
B4-BRACEKTRBHD	49	RH Curtain Holder	1
B4-BRACKETLBHD	50	LH Curtain Holder	1
B4-CURTAINBHD	51	Curtain	1
B4-SHELFBHD	52	Shelf	3
***	53	RH Shelf Bracket	3
***	54	Ticket Strip	3
***	55	LH Shelf Bracket	3
***	56	Wire Guard	1
***	57	Right Plastic Panel	1
***	58	Right Panel	1
B4-FANBHD	59	Fan Motor	1
***	60	Insulation	1
***	61	Handle Plate	1
***	62	Front Top Base Panel	1
***	63	Handle	1
***	64	Front Bottom Base Panel	1
B4-CONTROLLERBHD	65	Controller	1
B4-SWITHCBHD	66	On/Off Switch	1
B4-150BHD	67	125°C Klixon	1
B4-200BHD	68	150°C Klixon	1

*** Please contact Spares for assistance ***