


BR/BF1SS

Exploded parts diagram

Image shown is BF1SS







Part Number	Number	Name	Qty
***	1	Cabinet	1
X1-DOOR04	2	Door (BR1SS/BF1SS)	1
X1-GASKET04	3	Door Gasket (BR1SS/BF1SS)	1
X1-HINGE10	4	Spring Hinge (BR1SS/BF1SS)	1
X1-HINGE11	5	RH Upper Hinge (BR1SS/BF1SS)	1
K8-PROBE02	6	Evap Sensor	1
X1-SWITCH02	7	Light/Fan Switch (BR1SS/BF1SS)	1
X1-SWITCH01	8	Power Switch (BR1SS/BF1SS)	1
X1-CONTROLLER05	9	Controller (BF1SS)	1
X1-CONTROLLER04	9	Controller (BR1SS)	1
X1-COVER01	10	Light Cover (BR1SS/BF1SS)	1
X1-LED04	11	LED Light (BR1SS/BF1SS)	1
X1-LIGHTHOLDERBR	12	Light Box (BR1SS/BF1SS)	1
X1-LOCK04	13	Door Lock (BR1SS/BF1SS)	1
X1-PANEL01	14	Top Panel (BR1SS/BF1SS)	1
***	15	Motor Board	1
***	16	Evap. Fan Guard	1
***	17	Evap. Fan Blade	1
X1-FAN05	18	Evap Fan (BR1SS/BF1SS)	1
K8-CAPILLARY01	19	Capillary (BR1SS/BF1SS)	1
***	20	Drier	1
K8-COND03	21	Condenser (BF1SS)	1
K8-COND02	21	Condenser (BR1SS)	1
***	22	Cond. Fan Cover	1
***	23	Cond Fan Blade	1
X1-FAN06	24	Cond Fan Motor (BR1SS/BF1SS)	1
X1-COMP07	25	Compressor (BF1SS)	1
X1-COMP06	25	Compressor (BR1SS)	1
***	26	Cooling Unit Board	1
***	27	Sensor Clip	1
K8-PROBE02	28	Sensor (BR1SS/BF1SS)	1
***	29	Vaporising Tray	1
***	30	Vaporising Coil	1
X1-EVAP09	31	Evaporator (BF1SS)	1
X1-EVAP07	31	Evaporator (BR1SS)	1
X1-HEATER01	32	Defrost Heater (BF1)	1
***	33	Evaporator Drip Tray	1
***	34	Fan Plate	1
***	35	Top Cover	1
***	36	Power Cord	1
***	37	Ladder Rack	4
***	38	Ladder Rack Screw	8
X1-GUIDE01	39	Right Shelf Guide (pair) (BR1SS/BF1SS)	4

X1-SHELF06	40	Shelf (BR1SS/BF1SS)	4
***	41	Castor (unbraked)	2
X1-HINGE12	42	RH Bottom Hinge	1
X1-HINGEPIN	43	Hinge Pin	1
X1-HINGEBUSH	44	Bush	1
***	45	Cond. filter	1
X1-GUIDE01	46	Left Shelf Guide (pair)	4
***	47	Panel Connect	2
***	48	Castor (Braked)	2
***	49	Upper Hinge Cover	1

*** Please contact Spares for assistance ***

*Other model variant available;

Glass Door, BF1SSCR

Glass Door, BR1SSCR